



Installation

Model specific instructions

For:

- **Ducati Monster 696**
- **Ducati Monster 796**
- **Ducati Monster 1100 + 1100S**
- **Ducati Monster 1100 EVO**

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>

Installation Tips

- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- Install the BoosterPlug module as per the general installation papers.
- The AIT sensor is located in the air intake hose between the Air filter box and the throttle valve housing.
 - Ducati did not make it easy to reach the AIT sensor on these bikes, but if you remove the right hand cooling cover (the plastic cover that is placed above the front cylinder), you can reach the AIT sensor with a pair of needle nosed pliers.
- You have several choices for the BoosterPlug sensor location, but our favorite place is near the steering head or under the head light. Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

Pictures

For:

- **Monster 696 + 796**
- **Monster 1100 + 1100S + 1100 EVO**

