



Installation

Model specific instructions

For:

- KTM 390 Adventure

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed. (The red arrow and circles)
- The AIT sensor is located in the top of the air filter box - just below the rear end of the gas tank.
- Remove the seat and the plastic panels on either side of the gas tank.
- Remove the 3 screws that is holding the tank in place.
- Lift the rear end up slightly and support the tank with a block of wood.
- Now you have access to the AIT sensor (The red circle in the picture)
- Install the BoosterPlug and place the square BoosterPlug module between the air filter box and the frame (The Yellow circle)
- You have several choices for the BoosterPlug sensor location, but our favorite places are near the steering head, under the head light, or next to the airbox snorkel air intake hole.
 - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

Pictures

