



# Installation

Model specific instructions

For:

- KTM Freeride 350 (2012 and newer)
- KTM Freeride 250 F (2018 and newer)

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>

## Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed. (The red circle)
- The AIT sensor is located in air intake snorkel between the air filter and the throttle valve housing—beneath the gas tank.
- You can easily access the AIT sensor from the right hand side of the bike - see the picture below.
- You have several choices for the BoosterPlug sensor location, but our favorite place is near the steering head or under the head light. Next to the airbox snorkel air intake hole is another very good spot.
  - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

## Pictures

For:

- KTM Freeride 350 (2012 and newer)
- KTM Freeride 250 F (2018 and newer)

