



# Installation

Model specific instructions

For:

- Triumph Scrambler 1200 XC
- Triumph Scrambler 1200 XE

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>

## Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The picture below should help you locate the AIT sensor where the BoosterPlug is installed.
  - The AIT sensor is found in the right hand side of the air filter box.
  - **NOTE:** You will have to remove the rear part of the exhaust system to access the AIT sensor, but it is not too difficult - just follow the instructions in the pics below.
  - The BoosterPlug is a tight fit under the side cover, but it is possible to get everything in place. Take your time to position the BoosterPlug module before installing the side cover again.
  - One of the connector cables on the BoosterPlug is made longer than seen in the webshop pictures - This is to let you relocate the BoosterPlug module as there's not much room behind the side cover.
- You have several choices for the BoosterPlug sensor location, but our favorite place is near the steering head or under the head light. Next to the airbox snorkel air intake hole is another very good spot.
  - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

## Pictures

