



Installation

Model specific instructions

For:

- **Yamaha Ténéré 700**

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- Remove the right hand side fairing panel - 3 outside Torx screws and 3 inside Torx screws. (Yellow circles)
- Disconnect the connector to the right hand side indicator and remove the fairing panel.
- Remove the right hand side transparent wind deflector by removing the two Allen screws. (Yellow circles)
- The AIT sensor is located in the bottom of the dashboard and you can now remove the connector. (Red circle)
- Install the BoosterPlug to the two connectors and zip-tie the BoosterPlug sensor to the thick cable harness that goes to the dashboard.
- Reinstall the wind deflector and the fairing (and don't forget to connect the indicator again)

Pictures

