



Installation

Model specific instructions

For:

- Indian FTR1200
- Indian FTR1200S

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The picture below should help you locate the AIT sensor where the BoosterPlug is installed.
 - The AIT sensor is found in the intake manifold between the cylinder heads.
 - Remove the triangle cover on the left hand side of the bike to get access to the AIT sensor.
 - The AIT sensor is placed deep in the frame and is NOT easy to see or reach !
 - The AIT sensor is the one with the square white label.
 - Activate the latch on the connector with a schrewdriver to release it so you can pull off the connector
- Route the BoosterPlug sensor to the drain tube below the engine and zip-tie it in place (see the last picture)

Pictures

