



# Installation

Model specific instructions

For:

- **Triumph Bonneville T120**
- **Triumph Thruxton 1200**
- **Triumph Speed Twin**

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>


## Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The picture below should help you locate the AIT sensor where the BoosterPlug is installed.
  - The AIT sensor is found in the rear top of the air filter box.
  - **Bonneville T120:** Just remove the seat and you can access the AIT sensor in the top of the air filter box.
  - **Thruxton 1200:** If you have really long and slim fingers you may be able to reach the AIT sensor by removing the seat, but it's not easy due to the longer tank on the Thruxton. You probably have to lift the tank to get access, but it's not hard to do.
  - **Speed Twin:** Remove the seat and lift the rear part of the gas tank for easy access to the AIT sensor.
- You have several choices for the BoosterPlug sensor location, but our favorite place is near the steering head or under the head light. Next to the airbox snorkel air intake hole is another very good spot.
  - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

## Pictures

For:

- **Triumph Bonneville T120**



For:

- **Triumph Thruxton 1200**



For:

- **Triumph Speed Twin**

